

Anhang 4

In der nachfolgenden Tabelle sind die, in den Lizenzen eingetragenen Einschränkungs-Codes, aufgeschlüsselt. Es handelt sich hierbei um Einschränkungen die durch Umwandlung gemäß 66.A.70 i.V.m. 66.B.300 eingetragen wurden.

Code	Einschränkung
E001	Excluding adjustments and conditional inspections
E002	Excluding adjustments of autoflight systems
E003	Excluding adjustments of electro-mec. systems
E004	Excluding adjustments of electronic instrument and electrical systems
E005	Excluding adjustments of electronic instruments
E006	Excluding adjustments of electronic systems
E007	Excluding adjustments of engine performance
E008	Excluding adjustments of flight controls
E009	Excluding adjustments of mechanical systems
E010	Excluding APUs
E011	Excluding avionic LRUs
E012	Excluding complex adjustments
E013	Excluding conditional inspections
E014	Excluding deactivation with simple task of instrument / avionic systems
E015	[derzeit nicht verwendet]
E016	Excluding detailed troubleshooting / functional checks with complex equipment or without on board maintenance systems
E017	Excluding detailed troubleshooting on electronic instrument systems
E018	Excluding electrical power systems
E019	Excluding electronic instrument systems
E020	Excluding engine fire protection systems
E021	Excluding engine ground operation
E022	Excluding engine indication systems
E023	Excluding engine installation
E024	Excluding engine storage and preservation
E025	Excluding FADEC
E026	Excluding fire protection systems
E027	Excluding fly by wire
E028	Excluding gas turbine engine
E029	Excluding helicopter

Code	Einschränkung
E030	Excluding landing gear
E031	Excluding lubrication and replenishment of fluids and gases outside the cabin outside the cabin other than oxygen and water
E032	Excluding propeller
E033	Excluding repair of aircraft structure
E034	Excluding repair of electrical cable and connectors
E035	Excluding replacement and service on any components of gas turbine engine
E036	Excluding replacement and service on any components of turbo-prop, APU and turbo-shaft engine
E037	Excluding replacement of aircraft main and APU aircraft batteries
E038	Excluding replacement of brake units
E039	Excluding replacement of emergency equipment
E040	Excluding replacement of external lights
E041	Excluding replacement of inflight entertainment system components except those located on passenger seats
E042	Excluding replacement of lights
E043	Excluding replacement of seats
E044	Excluding replacement of static wicks
E045	Excluding replacement of toilet system components
E046	Excluding replacement of wheel assemblies
E047	Excluding replacement of windscreen wiper blades
E048	Excluding servo mechanical systems
E049	Excluding supersonic aircraft
E050	Excluding turbo-prop engine
E051	Excluding turbo-shaft engine